

Molality and Specific Heat Capacity

AkinFoluhan.A, Malachy.M, Mehdi.M

Experimental Objectives

- Examine how various salt molalities affect specific heat capacity
- Use the resistance of a thermistor to determine change in temperature
- Use LabView to take continuous temperature measurements over a period of time

Hypothesis

Our team hypothesized that due to the ionic interactions between the polar NaCl molecules and the water molecules, which would affect the hydrogen bonds between water molecules, which would mean less energy is required to break the existing bonds and raise the temperature of the water molecules. So we predict as the salt molality of the solution increases, the specific heat capacity of the solution will decrease.

Relevant Formulas

Chemistry-Based

- $Q = mc\Delta T$

Circuits-Based

- $P = V^2/R$


In a closed system (Thermodynamics)

- $Q = W$
- $W = P\Delta t$

Final Equation

$$C(p) = (V^2\Delta t)/(mR\Delta T)$$


Determining the resistance of the thermistor using the DAQ board:



$$\frac{V}{R} = \frac{V_k - V}{R_k} \Rightarrow R = \frac{V}{V_k - V} R_k$$

Equipment

- Protek DC Power Supply
- NI USB-6341 DAQ Board
- DigiKey 317-1378-ND Thermistor
- Immersive Water Heater
- DI (Deionized) Water
- Table Salt
- Styrofoam Cups
- Kitchen Scale
- BNC Cables
- Banana Clippers
- LabView Program




Experimental Set-Up

- Immersive water heater powered via DC Power Supply
- Thermistor powered and measured using DAQ board
- Thermistor and water heater both placed in solution

Thermistor Calibration

- Took temperatures at four different spots (ice bath, room, 90 degrees celsius water, and 80 degrees celsius water)



Setting	Temperature (Degrees Celsius)	Resistance (Kilo-Ohms)	DAQ Measured Resistance (Kilo-Ohms)	DAQ Measured Temperature (Celsius)	Temperature Difference (Degrees Celsius)
Ice Bath	1	159.6	163.339	0.9768	0.0232
Room	22	62.7	56.724	23.0247	-1.0247
Reference Temperature	90	5.11	5.09704	92.1	-2.1
Second Reference Temperature	80	6.68	6.64348	79.3156	0.6844

LabView Front Diagram

stop

STOP

Resistance

0

T(K)

0

T(C)

0

Time (s)

0


Efficiency Calibration

- DI Water Heat Capacity is known to be 4.184 J/g-C.
- We adjusted the heat capacity to account for the non perfect efficiency of the heater using the known value of the heat capacity of DI water.

	Trial 1	Trial 2	Trial 3	Trial 4	Trial 5	Trial 6
Initial Temperature (C)	22.1617	24.0679	25.7485	27.6023	29.1325	21.198
Final Temperature (C)	24.2166	25.2064	27.9919	29.5049	31.2886	22.1997
Change in Temperature (C)	2.0549	1.1385	2.2434	1.9026	2.1561	1.0017
Time Passed (s)	145.518	86.1665	167.442	142.605	153.377	71.374
Measured Heat Capacity (J/g-C)	5.115665034	5.467408108	5.391799846	5.414562054	5.138867429	5.147287633
Efficiency	81.7879977	76.52620615	77.5993197	77.27310092	81.41871838	81.28552936
Average Efficiency	78.92106857					
Adjusted Heat Capacity	4.037282845	4.314878479	4.255208439	4.273172373	4.055594175	4.0622394
Percent Error	3.506624173	3.12807072	1.701922527	2.131270859	3.068972868	2.910148186

Results

- An increase in salt molality led to a linear decrease in specific heat capacity
 - Implies a zero-specific heat capacity at a point
 - Likely levels off as molality approaches maximum amount
- More data points could reveal exact nature of relationship



	Concentration 1	Concentration 2	Concentration 3	Concentration 4
Molality of NaCl in DI Water (mol/kg)	0	0.6155240079	1.231048016	1.846572024
Average Measured Heat Capacity (J/g-C)	5.279265017	4.253687775	3.937131915	2.532610554
Average Adjusted Heat Capacity (J/g-C)	4.166395952	3.357055845	3.107226579	1.998763312

Challenges

- Calibrating for Heat Loss
 - Finding the specific heat capacity of DI Water
 - Calculating efficiency of immersion water heater
- Safety
 - Controlling output of heater via voltage
 - Properly grounding water heater
- Inconsistent temperature readings
 - Minimizing time needed for heater to reach max output
 - Keeping consistent water levels in styrofoam cups
 - Keeping consistent water heater and thermistor placement

Conclusions

- Maintaining a proper set-up throughout the duration of the experiment is vital for accurate calculations.
- Equipment issues can lead to issues with data collection.
- The table and graph indicated that the specific heat of a saltwater solution decreases with an increase in salt molality.